DAVID S M.E.N. CO. LTD

David & M.E.N. Co. Ltd

Motorway M2 Riche Terre Republic of Mauritius T +(230) 249 0171 F +(230) 249 0180 rimltd@intnet.mu www.davidmen.com VAT #: 20321585 Business Registration #: C07056727

As part of an ongoing commitment to customer satisfaction, David & M.E.N. Co. Ltd has supplied this information in good faith. David & M.E.N. Co. Ltd is not responsible and cannot in any way be held accountable for poor workmanship or errors that may occur through the use of this information.



CLADDING INSTALLATION SPECIFICATIONS

PREPARATION OF SURFACE

The surface on which the cladding is to be attached must be:

- Dry and free of any oil, dust, wax, flaking, crumbling or decomposition on the surface as this can prevent the cladding from adhering to the surface properly.
- In case of a new surface it must have cured properly (21 days) and must be dry.
- Where the surface is too smooth for the tile adhesive to adhere (painted) it must be chipped to give a rough finish or a rough primer must be applied.

METHOD

- Cladding is fixed to a surface like a normal ceramic or clay tile. A tile adhesive (tile fix) and bonding liquid (according to the manufacturers instructions), specific for stone work or a slurry consisting of one part cement and two parts plaster sand can be used.
- Apply the tile adhesive (tile fix) or slurry to the surface of the cladding and while it is still wet, fix the cladding to the wall.
- Leave a minimum space of 5 mm between the individual pieces. Use tile spacers.
- Start from the base of the wall and apply the cladding parallel to the floor of the building.
- Fit the cladding to the required height. Avoid long horizontal and vertical groutlines by breaking the lines after each piece. Allow to dry before starting grouting.
- Make a moist grouting consisting of tile adhesive (tile fix) or one part cement and three parts plaster sand.
- Apply the grouting into the spaces. Start from the highest point and work down. Make sure grouting is pressed well into the joins.
- Smooth out grouting with a sponge and water.
- NB! To avoid cement staining the cladding, wash grouting off cladding regularly and immediately, using water and a clean sponge.
- The dimensions for the subbase (only a guide);